

Ohio DOT Catch Basin No. 5 & 8 SedCage Installation

(SC42-18-sand)



The SedCage Sandbag model is compatible with grates that are not supported on all edges, like the Ohio DOT No. 5 and No. 8.



Position the SedCage over the grate and center it. Extend the geotextile flap out around SedCage.



Fill the provided sandbags half full with sand so they lay wide and flat. Optimum thickness is 2". Surround the SedCage with the sandbags.



SedCages only take minutes to install. They can be removed in minutes and reused. There is nothing to disassemble or haul to the dump. Finished grade is easier and more accurate because the concrete apron is exposed.



ODOT Catch Basin No. 5 and the SedCage "SC-42-sand". Note the amount of the 2x4 and silt fence method that would have been required due to the large concrete apron.