

Ohio DOT Catch Basin No. 4 SedCage Installation

(SC54-18-38p-sand)



Fill sandbags (provided) half full with sand or gravel so they will lie wide and flat. Optimum thickness is 2" Note the long apron in front of the grate. Large concrete aprons can double or triple the cost of installing 2x4s and silt fence around the perimeter of the grate.



Position the SedCage over the grate and center it. Extend geotextile flap out around SedCage. The camber of the SedCage matches up with the pitch of the grate.



Place sandbags on the flap surrounding the SedCage.



Remove sediment when it accumulates half the height of the SedCage.